



1. Before assembling as shown ensure that rubber 'O'rings are in place.
2. Assemble hand tight with sprays positioned correctly before using spanner provided to lock up.
3. Ensure that the hose is fully un-rolled with no kinks before turning on water supply
4. Turn on water supply, lower lid down until it sits on pedal.
5. Your shower is now ready for use by stepping on box lid.
6. After use dry unit before packing away.



ALPINE TECHNICAL SERVICES
 Midvale, UT 84047
800.747.9953
 ATSShieldSafe.com

TITLE	GPSS PORTABLE STAINLESS SHOWER				
Drg. No.	1112	Drawn	A Yates	Date	MAY97
Revision		Date			